

TANGENT™

Care & Cleaning Instructions





GENERAL CLEANING

- Scrub boards with soap and water solution using a soft sponge or plastic bristled brush.
- You can use a soft bristled toothbrush to clean spaces that are hard to reach.
- To remove surface dust, hose furniture down with cold, clear water.



DEEP CLEANING

- A pressure washer can be used on the lightest setting to deep clean your furniture.
- It is not recommended to use more than 1,500psi.
- Keep the tip of the pressure washer at least 10-12 inches from the furniture so it doesn't damage the lumber.

STAIN CHART

STAIN	RECOMMENDED CLEANING PROCESS
Pencil Marks	Use a solution of Dawn® dish soap and water to saturate the stain, then rinse with water
Ink/Marker	Use a solution of Dawn® dish soap and water to saturate the stain, then rinse with water. For tough stains, pretreat area with WD-40, wiping clean before using solution of water and Dawn® dish soap
Grease or Oil Stain	Use solution of Dawn® dish soap and water to saturate the stain, rinse with water
Embedded Dirt	Use solution of Dawn® dish soap to saturate the area, then scrub with a soft bristled brush, and rinse with water
Wine	Use solution of Dawn® dish soap to saturate the area, then scrub with a soft bristled brush, and rinse with water
Chewing Gum	Coat WD-40® lubricant or equivalent over the area. Gently pry up on any potentially hard articles slowly with a plastic putty knife. Utilize a soft brush & acetone solvent to remove any fine debris and clean out any crevasses. Rinse area with fresh water
Bird Droppings	Use solution of Dawn® dish soap to saturate the area, then scrub with a soft bristled brush, and rinse with water
Stains and Scuffs	A Magic Eraser™ may be used for stubborn marks
Iron and Rust	For tough stains from contact with iron, boards can be scrubbed with Iron Out™

Always read and follow the product manufacturers' specific instructions before using any cleaning product. If using alternative cleaning solutions than those outlined above, it is recommended to test the solution on an inconspicuous area of the lumber to make sure it does not harm the surface. For more information visit TangentMaterials.com